TECHNICAL INSERT

Item No	596	TraceAir®II Monitor for	Prepared by	CG
Edition	MARCH 2025	Phenol	Approved by	MDR Peralta

The TraceAir®II Personal Monitor is designed to measure exposure to chemicals in order to demonstrate workplace compliance with Permissible Exposure Limits (PELs) and Short Term Exposure Limits (STELs) defined by the Occupational Safety and Health Act of 1970 and Title 29 Code of Federal Regulations.

This **Technical Insert** contains product-specific information on use and storage.

9159-596 03/25

Sampling Medium:	Activated Carbon, 445 mg, PTFE Binder		
Sampling Medium.	Activated Carbon, 443 mg, FTFE Binder		
Analytes Sampled:	Phenol		
Analytical Method:	Modified OSHA 32. Desorption in carbon disulfide with appropriate co-solvent; analysis by High Performance Liquid Chromatography with an Ultraviolet Detector (HPLC-UV)		
Recommended Sampling Time:	STEL = 15 minutes PEL = 8 hours Cover removed for sampling		
	Functional Range: 15 min - 12 hours; Longer sampling times possible when analyte concentrations << PEL.		
Recommended Holding Time:	Monitors must be received by lab within two (2) weeks after sampling.		
Sample Capacity:	> 60 ppm for 8 hours (> 480 ppm-hrs)		
Reporting Limit (RL):	0.030 ppm for 8 hours		
*AT Labs specific	0.96 ppm for 15 minutes (0.24 ppm-hrs)		
Sampling Rate (SR):	90.3 mL/min		
Interfering Substance(s):	Organic vapors do not interfere if HPLC resolution is adequate.		
Effect of Temperature:	Effect on result ≤ 5% within 0 - 50°C (32 - 122°F).		
Effect of Humidity:	Functions as claimed within 10 – 80% RH.		
Accuracy (MTE):	Meets or exceeds OSHA requirements for accuracy: Maximum Total Error (MTE) ≤ 25% at PEL; ≤ 35% at STEL.		
Storage Conditions:	Store at controlled room temperature.		
_	Do Not Use after expiration date printed on pouch.		
IMPORTANT:	Warranty valid only if Instructions for Use have been followed.		
WARNING:	Wash affected area thoroughly if sampling medium is contacted.		

For detailed directions, see **Instructions for Use** included in each package of Monitors.

For detailed information about the TraceAir®II Personal Monitor, refer to AT Labs IH Sampling Guide at www.assaytech.com

Call TOLL FREE NUMBER 1-800-833-1258 or Email: custservice@assaytech.com